

SEAT BELT PRETENSIONER REMOVAL

BO258-01

NOTICE:

- If the wiring connector of the seat belt pretensioner is disconnected with the ignition switch at ON or ACC, diagnostic trouble codes will be recorded.
- Never use seat belt pretensioner from another vehicle. When replacing parts, replace them with new parts.

1. Regular cab:

REMOVE FRONT SEAT OUTER BELT

- Remove the bolt and front seat outer belt floor anchor.
- Using a screwdriver, open the cover, then unfatten the bolt and remove the front seat outer belt shoulder anchor.

HINT:

Tape the screwdriver tip before use.


- Remove the clip and retractor cover.
- Remove the retractor of front seat outer belt.

CAUTION:

Never disassemble the front seat outer belt.

NOTICE:

When removing the retractor of front seat outer belt, take care not to pull the seat belt pretensioner wire harness.



- (1) Disconnect the pretensioner connector as shown in the illustration.

CAUTION:

When removing the seat belt pretensioner, work must be started 90 seconds after the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.


- (2) Remove the 2 bolts and retractor of front seat outer belt.

2. Extra cab:

REMOVE FRONT SEAT OUTER BELT

- Remove the 4 screws and door suff plate.

BODY - SEAT BELT PRETENSIONER




(b) Using a screwdriver, remove the back panel upper garnish.

HINT:

Tape the screwdriver tip before use.

(c) Remove the 3 bolts and back panel trim.



(d) Using a screwdriver, remove the back panel lower garnish.

HINT:

Tape the screwdriver tip before use.


(e) Remove the 4 bolts and rear seat cushions.

(f) Remove the front and rear seat outer belt shoulder anchors.

Using a screwdriver, open the covers, then unfatten the bolts and remove the front and rear seat outer belt shoulder anchors.

HINT:

Tape the screwdriver tip before use.




(g) Remove the lock handle.

(1) Using a screwdriver, remove the cover.

HINT:

Tape the screwdriver tip before use.

(2) Remove the 2 screws and lock handle.



(h) Remove the quarter trim.

(1) Remove the 2 bolts and front and rear seat outer belt floor anchors.

(2) Remove the screw and coat hook.

(3) Using a screwdriver, remove the quarter trim.

NOTICE:

Paying enough attention remove the clip on the quarter trim shown in the illustration. Otherwise, the quarter trim or the front pillar garnish might be broken.

HINT:

Tape the screwdriver tip before use.

- (i) Remove the retractor of front seat outer belt.

CAUTION:

Never disassemble the front seat outer belt.

NOTICE:

When removing the retractor of front seat outer belt, take care not to pull the seat belt pretensioner wire harness.

- (1) Disconnect the retractor switch connector.
- (2) Disconnect the pretensioner connector as shown in the illustration.

CAUTION:

When removing the seat belt pretensioner, work must be started 90 seconds after the ignition switch is turned to the "LOCK" position and the negative (-) terminal cable is disconnected from the battery.

- (3) Remove the 2 bolts and retractor of front seat outer belt.

