


I GROUND POINT



I GROUND POINT

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
J9	29 (5VZ-FE)	J10	29 (5VZ-FE)		
	31 (3RZ-FE, 2RZ-FE)		31 (3RZ-FE, 2RZ-FE)		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IG1	40	Cowl Wire and Roof Wire (Left Kick Panel)
IH2	40	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IJ1	40	Cowl Wire and A/C Sub Wire (Behind the Glove Box)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
IK5		
IL2	40	Front Door RH Wire and Cowl Wire (Right Kick Panel)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)
BO1	42	Frame Wire and Diff. Lock Wire (Rear Side Member LH)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE, 2RZ-FE)	
EB	36 (5VZ-FE)	Near the Throttle Body
	38 (3RZ-FE, 2RZ-FE)	Under the Data Link Connector 1
EC	36 (5VZ-FE)	Front Right Fender
	38 (3RZ-FE, 2RZ-FE)	
EF	38 (3RZ-FE)	Ignition Coil Bracket
ID	40	Left Kick Panel
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement
IH	40	Right Kick Panel

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I1	40	Cowl Wire	B1	42	Front Door LH Wire
I5			B4	42	Frame Wire
I6			B5	42	Front Door RH Wire
I7			B6	42	Frame Wire
I9					
I10			40	Engine Wire	B8
I11	40	Cowl Wire			

