


INSPECTION

- 1. w/o Cruise Control:
INSPECT STOP LIGHT SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
Switch pin free (Brake pedal depressed)	1 - 2	Continuity
Switch pin pushed in (Brake pedal released)	-	No continuity

If continuity is not as specified, replace the switch.



- 2. w/ Cruise Control:
INSPECT STOP LIGHT SWITCH CONTINUITY**

Switch position	Tester connection	Specified condition
Switch pin free (Brake pedal depressed)	1 - 2	Continuity
Switch pin pushed in (Brake pedal released)	-	No continuity

If continuity is not as specified, replace the switch.