


ADJUSTMENT

1. ADJUST DOOR IN FORWARD/ REARWARD AND VERTICAL DIRECTIONS

Using SST, adjust the door by loosening the body side hinge bolts.

SST 09812-00010

Torque: 23 N·m (230 kgf·cm, 17 ft·lbf)



2. ADJUST DOOR IN LEFT/ RIGHT AND VERTICAL DIRECTIONS


Loosen the door side hinge bolts to adjust.

HINT:

Substitute the standard bolt for the centering bolts.

(See page [BO-7](#))

Torque: 23 N·m (230 kgf·cm, 17 ft·lbf)



3. ADJUST DOOR LOCK STRIKER

- Check that the door fit and door lock linkages are adjusted correctly.
- Adjust the striker position by slightly loosening the striker mounting screws, and hitting the striker with a hammer.
- Tighten the striker mounting screws again.

Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)