

## DIAGNOSTIC TROUBLE CODE CHART

If a DTC is displayed during the DTC check, check the circuit listed for that code in the table below and proceed to the page given.

DTC No. (See Page)	Detection Item	Trouble Area	MIL *	Memory
P0500 3RZ-FE: (DI-129) 5VZ-FE (DI-294)	Vehicle Speed Sensor Malfunction (No.1 Vehicle Speed Sensor)	<ul style="list-style-type: none"> <li>• Open or short in No.1 vehicle speed sensor circuit</li> <li>• No.1 vehicle speed sensor</li> <li>• Combinationmeter</li> <li>• ECM</li> </ul>	●	○
P0710 (DI-369)	Transmission Fluid Temperature Sensor Malfunction (ATF Temperature Sensor)	<ul style="list-style-type: none"> <li>• Open or short in ATF temperature sensor circuit</li> <li>• ATF temperature sensor</li> <li>• ECM</li> </ul>	●	○
P0750 (DI-371)	Shift Solenoid A Malfunction (Shift Solenoid Valve No.1)	<ul style="list-style-type: none"> <li>• Shift solenoid valve No.1 is stuck open or closed</li> <li>• Valve body is blocked up or stuck</li> </ul>	●	○
P0753 (DI-373)	Shift Solenoid A Electrical Malfunction (Shift Solenoid Valve No.1)	<ul style="list-style-type: none"> <li>• Open or short in shift solenoid valve No.1 circuit</li> <li>• Shift solenoid valve No.1</li> <li>• ECM</li> </ul>	●	○
P0755 (DI-371)	Shift Solenoid B Malfunction (Shift Solenoid Valve No.2)	<ul style="list-style-type: none"> <li>• Shift solenoid valve No.2 is stuck open or closed</li> <li>• Valve body is blocked up or stuck</li> </ul>	●	○
P0758 (DI-373)	Shift Solenoid B Electrical Malfunction (Shift Solenoid Valve No.2)	<ul style="list-style-type: none"> <li>• Open or short in shift solenoid valve No.2 circuit</li> <li>• Shift solenoid valve No.2</li> <li>• ECM</li> </ul>	●	○
P0770 (DI-378)	Shift Solenoid E Malfunction (Shift Solenoid Valve SL)	<ul style="list-style-type: none"> <li>• Shift solenoid valve SL is stuck open or closed</li> <li>• Valve body is blocked up or stuck</li> <li>• Lock-up clutch</li> </ul>	●	○
P0773 (DI-380)	Shift Solenoid E Electrical Malfunction (Shift Solenoid Valve SL)	<ul style="list-style-type: none"> <li>• Open or short in shift solenoid valve SL circuit</li> <li>• Shift solenoid valve SL</li> <li>• ECM</li> </ul>	●	○
P1520 3RZ-FE: (DI-384) 5VZ-FE (DI-319)	Stop Light Switch Signal Malfunction	<ul style="list-style-type: none"> <li>• Short in stop light switch signal circuit</li> <li>• Stop light switch</li> <li>• ECM</li> </ul>	●	○
P1700 (DI-385)	Vehicle Speed Sensor No.2 Malfunction (No.2 Vehicle Speed Sensor)	<ul style="list-style-type: none"> <li>• Open or short in No.2 vehicle speed sensor circuit</li> <li>• No.2 vehicle speed sensor</li> <li>• ECM</li> </ul>	●	○
P1780 (DI-389)	Park/Neutral Position Switch Malfunction	<ul style="list-style-type: none"> <li>• Short in park/neutral position switch circuit</li> <li>• Park/neutral position switch</li> <li>• ECM</li> </ul>	●	○

\* : ●...MIL light up