



INSTALLATION

NOTICE:

Never use airbag parts from another vehicle. When replacing parts, replace with new parts.



1. **INSTALL FRONT PASSENGER AIRBAG ASSEMBLY**
 - (a) Install the airbag door and instrument panel stay to the instrument panel.




- (b) Install the front passenger airbag assembly to the instrument panel.

CAUTION:

Make sure that no foreign objects are trapped between the airbag door and bag, and within the module.

NOTICE:

If the front passenger airbag assembly has been dropped, or there are cracks, dents or other defects in the case or connector, replace the front passenger airbag assembly with a new one.




2. **INSTALL INSTRUMENT PANEL** (See page [BO-52](#))

Install the 2 bolts to instrument panel reinforcement.

Torque: 20 N·m (205 kgf-cm, 15 ft-lbf)


NOTICE:

- Make sure the front passenger airbag assembly is installed to the specified torque.
- When installing the instrument panel, take care that the airbag wire harness does not interfere with other parts and is not pinched between other parts.



3. **CONNECT AIRBAG CONNECTOR**

- (a) Connect the airbag connector.



(b) Install the glove compartment door.