

# RADIATOR

## ON-VEHICLE CLEANING

CO0X8-01

Using water or a steam cleaner, remove any mud or dirt from the radiator core.

**NOTICE:**

**If using a high pressure type cleaner, be careful not to deform the fins of the radiator core. (i.e. Maintain a distance between the cleaner nozzle and radiator core)**