


REMOVAL

1. DRAIN ENGINE COOLANT FROM RADIATOR

HINT:


It is not necessary to drain out all the coolant.



2. DISCONNECT WATER VALVE CONTROL CABLE FROM WATER VALVE


HINT:

At the time of installation, please refer to the following item
For installing the control cable, refer to "INSTALLATION" of
HEATER CONTROL ASSEMBLY on page [AC-93](#).




3. DISCONNECT WATER HOSES

- Using pliers, grip the claws of the clip and slide the clip along the hose.
- Disconnect the water hose.



HINT:

At the time of installation, please refer to the following item.
Install the hose clip in the position, as shown in the illustration.



4. REMOVE WATER VALVE

Remove the bolt and water valve.