


N13931

## REMOVAL

### 1. REMOVE SERVICE HOLE COVER

Remove the 12 screws and service hole cover.

### 2. DISCONNECT TAIL GATE LOCK LINK FROM TAIL GATE LOCK CONTROL



N16123

### 3. REMOVE TAIL GATE CABLE

- Disconnect the tail gate cable from the tail gate.
- Remove the bolt and tail gate cable from the body.
- Employ the same manner described above to the other side.

**Torque: 14 N·m (140 kgf·cm, 10 ft·lbf)**


### 4. REMOVE TAIL GATE LOCK FROM TAIL GATE

- Remove the 2 screws and tail gate lock.
- Employ the same manner described above to the other side.

### 5. REMOVE TAIL GATE LOCK STRIKERS

Remove the 4 screws and tail gate lock strikers.

**Torque: 12 N·m (120 kgf·cm, 9 ft·lbf)**



N16122

### 6. REMOVE TAIL GATE

Remove the 4 screws and tail gate.

**Torque:**

**A: 28 N·m (290 kgf·cm, 19 ft·lbf)**

### 7. REMOVE TAIL GATE HINGE


- Remove the 2 bolts and tail gate hinge.

**Torque:**

**B: 30 N·m (310 kgf·cm, 22 ft·lbf)**

**C: 24 N·m (290 kgf·cm, 19 ft·lbf)**

- Employ the same manner described above to the other side.

**8. REMOVE TAIL GATE LOCK CONTROL**

Remove the 2 bolts and tail gate lock control.