

## REASSEMBLY

### 1. INSTALL FRONT SEAT INNER BELT

Install the front seat inner belt with the nut to the inner track.

**Torque: 41 N·m (420 kgf·cm, 30 ft·lbf)**

### 2. INSTALL EQUALIZING WIRE

### 3. INSTALL INSIDE OUTER SHIELD

Install the inside outer shield with the screw.

### 4. INSTALL INSIDE INNER SHIELD

Install the inside inner shield with the screw.

### 5. INSTALL RECLINING CONNECTING PIPE

(a) Adjust the reclining lock positions of the seat tracks.

(b) Slide the seat track to the most front position.

(c) Place the seat track on a spacer to adjust the seat rails in parallel and install the connecting pipe.

HINT:

When installing the connecting pipe while raising up the seat tracks, the lock positions adjusted in 5–(a) step slip off then lock error will occur.

### 6. INSTALL SEATBACK COVER

(a) Install the seatback cover with new hog rings to the seatback pad.

HINT:

When installing the hog rings, take care to prevent wrinkles as little as possible.

(b) Driver's seat:

Install the lumber support assembly and spacer with the 2 bolts.

(c) Install the seatback cover with pad to the seatback frame.

(d) Driver's seat:

Install the lumber support lever.

(e) Install the headrest support.

### 7. INSTALL SEATBACK ASSEMBLY

Install the seat back assembly with 4 bolts.

**Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)**

HINT:

Tighten the 4 bolts temporarily, then from the bolt on the front right side tighten completely.

### 8. INSTALL SEAT CUSHION COVER

(a) Install the seat cushion cover with new hog rings to the seat cushion pad.

HINT:

When installing the hog rings, take care to prevent wrinkles as little as possible.

(b) Install the seat cushion cover with pad to the seat cushion frame.

### 9. INSTALL SEAT CUSHION ASSEMBLY

Install the seat cushion assembly with 4 bolts to the seat track.

**Torque: 18 N·m (185 kgf·cm, 13 ft·lbf)**

HINT:

Tighten the 4 bolts temporarily, then from the bolts on the rear side tighten completely.

### 10. INSTALL INNER SHIELD

Install the inner shield with the screw.

### 11. INSTALL OUTER SHIELD

Install the outer shield with the screw.

### 12. INSTALL SEAT ADJUSTER KNOB

### 13. INSTALL RECLINING ADJUSTER RELEASE HANDLE

### 14. INSTALL HEADREST