




# ELECTRONICALLY CONTROLLED TRANSMISSION



# (3RZ-FE EXCEPT CALIFORNIA)



# ELECTRONICALLY CONTROLLED TRANSMISSION



# (3RZ-FE EXCEPT CALIFORNIA)

## SYSTEM OUTLINE

Previous automatic transmissions have selected each gear shift using mechanically controlled throttle hydraulic pressure, governor hydraulic pressure and lock-up hydraulic pressure. The electronically controlled transmission, however, electrically controls the governor pressure and lock-up pressure through the solenoid valve. Control of the solenoid valve by the engine control module based on the input signals from each sensor makes smooth driving possible by shift selection for each gear which is most appropriate to the driving conditions at that time.

### 1. GEAR SHIFT OPERATION

During driving, the engine control module selects the shift for each gear which is most appropriate to the driving conditions, based on input signals from the engine coolant temp. sensor to TERMINAL THW of the engine control module, and also the input signals to TERMINAL SP2+ of the engine control module from the vehicle speed sensor devoted to the electronically controlled transmission. Current is then output to the electronically controlled transmission solenoid. When shifting to 1st speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and continuity to the No.1 solenoid causes the shift.

For 2nd speed, current flows from TERMINAL S1 of the engine control module to TERMINAL 1 of the electronically controlled transmission solenoid to GROUND, and from TERMINAL S2 of the engine control module to TERMINAL 2 of the electronically controlled transmission solenoid to GROUND, and continuity to solenoid No.1 and No.2 causes the shift.

For 3rd speed, there is no continuity to No.1 solenoid, only to No.2 causing the shift. Shifting into 4th speed (Overdrive) takes place when there is no continuity to either No.1 or No.2 solenoid.

### 2. LOCK-UP OPERATION

When the engine control module judges from each signal that lock-up operation conditions have been met, current flows from TERMINAL SL of the engine control module to TERMINAL 3 of the electronically controlled transmission solenoid to GROUND, causing continuity to the lock-up solenoid and causing lock-up operation.

### 3. STOP LIGHT SW CIRCUIT

If the brake pedal is depressed (Stop light SW on) when driving in lock-up condition, a signal is input to TERMINAL BK of the engine control module, the engine control module operates and continuity to the lock-up solenoid is cut.

### 4. OVERDRIVE CIRCUIT

#### \* O/D main SW on

When the O/D main SW is turned on (SW point is open), a signal is input to TERMINAL ODMS of the engine control module and engine control module operation causes gear shift when the conditions for overdrive are met.

#### \* O/D main SW off

When the O/D main SW is turned off (SW point is closed), a signal is input into TERMINAL ODMS of the engine control module, and turns on the O/D off indicator light. This activates the ECU, and the transmission system is controlled not to shift to overdrive.

# ELECTRONICALLY CONTROLLED TRANSMISSION

## SERVICE HINTS

### E2 ELECTRONICALLY CONTROLLED TRANSMISSION SOLENOID

1, 2, 3-GROUND : Approx. 13 Ω

### P1 A/T INDICATOR LIGHT SW [PARK/NEUTRAL POSITION SW]

4-GROUND : Approx. 12 volts with ignition SW ON position

### S5 (A), (B) STOP LIGHT SW

(A) 2-(A) 1, (B) 2-(B) 1 : Closed with brake pedal depressed

### E 5 (A), E 6 (B), E 7 (C), E 8 (D) ENGINE CONTROL MODULE

S1-E1 : 9-14 volts

S2, SL-E1 : 0-1.5 volts

BK-E1 : 7.5-14 volts with brake pedal depressed  
: 0-1.5 volts with brake pedal released

THW-E2 : 0.2-1.0 volts with coolant temp. 80°C (176°F)

OIL-E2 : 4-5 volts with fluid temp. 20°C (68°F)

VTA-E2 : 0.3-0.8 volts with throttle valve fully closed  
: 3.2-4.9 volts with throttle valve fully open

VC-E2 : 4.5-5.5 volts

OD1-E1 : 4.5-5.5 volts

ODMS-E1 : 9-14 volts O/D main SW turned on  
: 0 volts O/D main SW turned off

SP1-E1 : Pulse generation with vehicle moving

2-E1 : 10-14 volts with shift lever at 2 position

: 0-2 volts with shift lever at except 2 position

L-E1 : 10-14 volts with shift lever at L position

: 0-2 volts with shift lever at except L position

R-E1 : 10-4 volts with shift lever at R position

0-2 volts with shift lever at except R position

PWR-E1 : 7.5-14 volts with pattern select SW PWR position

0-1.5 volts with pattern select SW NORM position

+B-E1 : 9-14 volts

BATT-E1 : 9-14 volts

## ○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A7	30 (3RZ-FE)	E4	33	J12	33
C10	A 32	E5	A 33	P1	31 (3RZ-FE)
C12	C 32	E6	B 33	S4	33
C13	D 32	E7	C 33	S5	A 33
C17	32	E8	D 33		B 33
D1	30 (3RZ-FE)	F5	33	T1	31 (3RZ-FE)
D4	30 (3RZ-FE)	J9	A 31 (3RZ-FE)	V1	31 (3RZ-FE)
E2	30 (3RZ-FE)	J10	B 31 (3RZ-FE)	V10	31 (3RZ-FE)
E3	30 (3RZ-FE)	J11	33		

## ○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

## (3RZ-FE EXCEPT CALIFORNIA)

### : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3E		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

### : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
IK3		

### : GROUND POINTS

Code	See Page	Ground Points Location
EA	38 (3RZ-FE)	Front Left Fender
EB	38 (3RZ-FE)	Near the Throttle Body
ID	40	Left Kick Panel
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

### : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	I9	40	Cowl Wire
I7					