


Ts Terminal Circuit

CIRCUIT DESCRIPTION

The sensor check circuit detects abnormalities in the speed sensor signal which cannot be detected with the DTC check.


Connecting terminals Ts and E₁ of the DLC1 in the engine compartment starts the check.

WIRING DIAGRAM



INSPECTION PROCEDURE

- | | |
|----------|--|
| 1 | Check voltage between terminals Ts and E₁ of DLC1. |
|----------|--|



CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals Ts and E₁ of DLC1.

OK:

Voltage: 10 - 14 V

OK → If ABS warning light does not blink even after Ts and E₁ are connected, the ECU may be defective.

NG

2	Check for open and short in harness and connector between ABS actuator and DLC1, DLC1 and body ground (See page IN-28).
---	--

NG**Repair or replace harness or connector.****OK****Check and replace ABS ECU.**