



STEERING**SST (Special Service Tools)**


PP09I-03

	09521-24010	Drive Shaft Boot Clamping Tool	PS gear (2WD)
	09527-20011	Rear Axle Shaft Bearing Remover	PS gear (2WD)
	09608-04031	Front Hub Inner Bearing Cone Replacer	PS vane pump (2RZ-FE, 3RZ-FE)
	09612-00012	Rack & Pinion Steering Rack Housing Stand	Manual steering gear PS gear (2WD, 4WD and Pre runner)
	09612-22011	Tilt Handle Bearing Replacer	PS gear (2WD)
	09612-24014	Steering Gear Housing Overhaul Tool Set	
	(09613-22011)	Steering Rack Shaft Bushing Puller	PS gear (2WD)
	(09616-10010)	Steering Pinion Bearing Adjusting Socket	Manual steering gear
	09616-00010	Steering Worm Bearing Adjusting Socket	PS gear (2WD, 4WD and Pre runner)
	09631-00350	Steering Rack Cover 35	PS gear (4WD and Pre runner)
	09631-10021	Rack Stopper Wrench	Manual steering gear PS gear (2WD)
	09631-10030	Oil Seal Remover	PS vane pump (2RZ-FE, 3RZ-FE)

PREPARATION - STEERING


	09631-12071	Steering Rack Oil Seal Test Tool	PS gear (2WD, 4WD and Pre runner)
	09631-20060	Bearing Guide Nut Wrench	PS gear (4WD and Pre runner)
	09631-20081	Seal Ring Tool	PS gear (2WD, 4WD and Pre runner)
	09631-20102	Steering Rack Cover "H"	PS gear (2WD)
	09631-22020	Power Steering Hose Nut 14 x 17 mm Wrench Set	PS gear (2WD, 4WD and Pre runner)
	09633-00020	Power Steering Hose Nut Wrench	PS gear (2WD, 4WD and Pre runner)
	09640-10010	Power Steering Pressure Gauge Set	
	(09641-01010)	Gauge Assy	Power steering fluid
	(09641-01030)	Attachment B	Power steering fluid
	(09641-01060)	Attachment E	Power steering fluid
	09922-10010	Variable Open Wrench	Manual steering gear PS gear (2WD, 4WD and Pre runner)
	09950-40011	Puller B Set	
	(09958-04011)	Holder	Tilt steering column

PREPARATION - STEERING

	<p>09950-50012 Puller C Set</p>	
	<p>(09951-05010) Hanger 150</p>	<p>Non-tilt steering column Tilt steering column</p>
	<p>(09952-05010) Slide Arm</p>	<p>Non-tilt steering column Tilt steering column</p>
	<p>(09953-05010) Center Bolt 100</p>	<p>Non-tilt steering column Tilt steering column</p>
	<p>(09954-05020) Claw No.2</p>	<p>Non-tilt steering column Tilt steering column</p>
	<p>09950-60010 Replacer Set</p>	
	<p>(09951-00180) Replacer 18</p>	<p>PS gear (2WD, 4WD and Pre runner)</p>
	<p>(09951-00240) Replacer 24</p>	<p>PS gear (2WD)</p>
	<p>(09951-00250) Replacer 25</p>	<p>Manual steering gear PS gear (2WD)</p>
	<p>(09951-00260) Replacer 26</p>	<p>PS gear (2WD, 4WD and Pre runner)</p>
	<p>(09951-00280) Replacer 28</p>	<p>PS gear (2WD, 4WD and Pre runner)</p>
	<p>(09951-00310) Replacer 31</p>	<p>PS gear (2WD)</p>
	<p>(09951-00320) Replacer 32</p>	<p>PS gear (2WD, 4WD and Pre runner)</p>

PREPARATION - STEERING

	(09951-00330) Replacer 33	PS vane pump (5VZ-FE) PS gear (2WD, 4WD and Pre runner)
	(09951-00360) Replacer 36	PS gear (4WD and Pre runner)
	(09951-00400) Replacer 40	PS gear (2WD)
	(09951-00420) Replacer 42	PS gear (2WD)
	(09951-00490) Replacer 49	PS gear (4WD and Pre runner)
	(09952-06010) Adapter	PS gear (4WD and Pre runner)
	09950-70010 Handle Set	
	(09951-07100) Handle 100	PS vane pump (5VZ-FE) Manual steering gear PS gear (4WD and Pre runner)
	(09951-07150) Handle 150	PS gear (2WD, 4WD and Pre runner)
	(09951-07200) Handle 200	PS gear (2WD)
	(09951-07360) Handle 360	PS gear (2WD, 4WD and Pre runner)
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	PS vane pump (2RZ-FE, 3RZ-FE, 5VZ-FE)

	(09963-01000) Pin 10	PS vane pump (2RZ-FE, 3RZ-FE, 5VZ-FE)
---	----------------------	---------------------------------------