


## REMOVAL

1. w/ Removable roof:  
REMOVE SUNSHADE TRIM
2. w/ Removable roof:  
REMOVE REMOVABLE ROOF LOCK HANDLE AND LOCK BASE
3. w/ Removable roof:  
REMOVE SLIDING ROOF OPENING TRIM
4. REMOVE ASSIST GRIPS
5. REMOVE SUN VISORS AND HOLDERS
6. REMOVE INNER REAR VIEW MIRROR
7. REMOVE ROOM LIGHT
8. REMOVE COWL SIDE TRIMS
9. REMOVE FRONT DOOR SCUFF PLATES
10. REMOVE DOOR OPENING TRIMS



### 11. REMOVE BACK PANEL UPPER GARNISH AND BACK PANEL TRIM


- (a) Using a screwdriver, remove the garnish.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 3 bolts and trim.

**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**



### 12. REMOVE BACK PANEL LOWER GARNISH

Using a screwdriver, remove the garnish.

HINT:

Tape the screwdriver tip before use.

### 13. REMOVE REAR SEAT CUSHIONS


Remove the 4 bolts and rear seat cushions.

**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**

### 14. REMOVE FRONT AND REAR SEAT OUTER BELT SHOULDER ANCHORS

Remove the 4 bolts and outer belt shoulder anchors.

**Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)**


**15. REMOVE LOCK HANDLE**

- (a) Using a screwdriver, remove the cover.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 2 screws and lock handle.  
 (c) Employ the same manner described above to the other side.

**16. REMOVE QUARTER TRIM**

- (a) Remove the screw and coat hook.

- (b) Using a screwdriver, remove the quarter trim.

HINT:

Tape the screwdriver tip before use.

**NOTICE:**

**Paying enough attention remove the clip on the quarter trim shown in the illustration. Otherwise, the quarter trim or the front pillar garnish might be broken.**

- (c) Employ the same manner described above to the other side.

**17. REMOVE FRONT PILLAR GARNISHES****18. REMOVE ROOF HEADLINING**

- (a) Using a clip remover, remove the 2 clips.

- (b) Remove the roof headlining.