

R13556

REMOVAL

1. INSPECT SHOE LINING THICKNESS


Remove the inspection hole plug, and check the shoe lining thickness through the hole.

If less than minimum, replace the shoes.

Minimum thickness: 1.0 mm (0.039 in.)

2. REMOVE REAR WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)



BR3116


3. REMOVE BRAKE DRUM

- (a) Release the parking brake lever and remove the brake drum.

HINT:

If the brake drum cannot be removed easily, do the following steps.


- (b) Remove the adjusting hole plug from the backing plate.
 (c) Insert a screwdriver through the hole in the backing plate, and hold the automatic adjusting lever away from the adjusting bolt.
 (d) Using another screwdriver, reduce the brake shoe adjustment by turning the adjusting bolt.



R13557


4. REMOVE REAR SHOE

- (a) Using SST, disconnect the return spring.
 SST 09703-30010



R13559


- (b) Using SST, remove the shoe hold-down spring, 2 cups and pin.
 SST 09718-00010
 (c) Disconnect the anchor spring from the rear shoe and remove the rear shoe.
 (d) Remove the anchor spring from the front shoe.

**5. REMOVE FRONT SHOE**

- (a) Using SST, remove the shoe hold-down spring, 2 cups and pin.
SST 09718-00010
- (b) Remove the return spring from the front shoe.
- (c) Disconnect the parking brake cable No. 1 from the parking brake bellcrank No. 3.
- (d) Remove the front shoe with adjuster.
- (e) Disconnect the parking brake cable No. 1 from the front shoe.

6. REMOVE ADJUSTER FROM FRONT SHOE

- (a) Remove the adjusting lever spring.
- (b) Remove the adjuster.

**7. REMOVE AUTOMATIC ADJUSTING LEVER AND PARKING BRAKE LEVER**


- (a) Remove the E-ring.
- (b) Remove the automatic adjusting lever.
- (c) Remove the C-washer.
- (d) Remove the parking brake lever.

8. REMOVE AND DISASSEMBLE PARKING BRAKE BELLCRANK


- (a) Remove the clip and disconnect the parking brake cable.
- (b) Remove the tension spring.
- (c) Using a screwdriver, remove the C-washer and bellcrank No. 3 from the backing plate with parking brake rod.
- (d) Remove the 2 bolts, parking brake bellcrank and dust cover.


Torque: 13 N·m (130 kgf-cm, 9 ft-lbf)

- (e) Remove the bellcrank boot from the bellcrank bracket.



- (f) Remove the C-washer and pin.
- (g) Remove the parking brake bellcrank from the bellcrank bracket.



**9. REMOVE WHEEL CYLINDER**

- (a) Using SST, disconnect the brake line. Use a container to catch the brake fluid.

SST 09023-00100

Torque: 15 N·m (155 kgf-cm, 11 ft-lbf)

- (b) Remove the 2 bolts and the wheel cylinder.

Torque: 10 N·m (100 kgf-cm, 7 ft-lbf)

10. DISASSEMBLE WHEEL CYLINDER

- (a) Remove the 2 boots, 2 pistons and spring.
(b) Remove the 2 piston cups from each piston.