




CIRCUIT



w/ Tachometer



No.	Wire Harness Side	
A	1 GAUGE Fuse	
	4 Park/Neutral Position Switch	
	5 Transfer Neutral Position Switch	
	6 A/T Oil Temperature Switch	
	8 Cruise Control ECU	
	7 Rear Differential Lock Switch	
	9 ABS ECU	
	10 IGN Fuse	
	11 Engine Coolant Temperature Sender Gauge	
	12 Ground	
	13 Generator L Terminal	
	14 Low Oil Pressure Warning Switch	
	15 TAIL Fuse	
	16 Light Control Rheostat	
	B	1 Ground
		2 Parking Brake Switch
3 Seat Belt Buckle Switch		
4 ECU - B Fuse		
5 Airbag Sensor Assembly		
6 O/D OFF Switch		
7 STARTER Relay		
8 Right Turn Signal Switch		
9 Headlight Dimmer Switch		
10 Left Turn Signal Switch		
C	1 Park/Neutral Position Switch *	
	2 Park/Neutral Position Switch *	
	3 Park/Neutral Position Switch *	
	4 Park/Neutral Position Switch *	
	5 Park/Neutral Position Switch *	
	6 Park/Neutral Position Switch *	
D	1 DOME Fuse	
	2 Vehicle Speed Sensor	
	3 ECM	
	5 GAUGE Fuse	
	6 Fuel Sensor Gauge	
	7 Ground	
	8 Ground	
	9 ECM	
	10 Transfer Indicator Switch	
	11 Fuel Level Warning Switch	
	12 Washer Level Warning Switch	
	13 Pattern Select Switch	

* : Column A/T

P

I01917