


## HEATER RADIATOR REMOVAL

AC08B-01

1. REMOVE HEATER UNIT  
(See page [AC-30](#))



2. REMOVE HEATER RADIATOR
  - (a) Remove 3 screws and 3 plates and clamp.
  - (b) Pull the radiator upward.