


INSPECTION


1. INSPECT ROOM LIGHT SWITCH CONTINUITY

- (a) Disconnect the connector from room light switch.
- (b) Turn the room light switch ON, check that continuity exists between terminal 2 and body ground.



- (c) Turn the room light switch to DOOR, check that there is continuity between terminals 1 and 2.

If operation is not as specified, replace the switch.



2. INSPECT DOOR COURTESY SWITCH CONTINUITY

- (a) Check that continuity exists between terminal and the switch body in the ON position (switch pin released : opened door).
- (b) Check that no continuity exists between terminal and the switch body in the OFF position (switch pin pushed in : closed door).

If operation is not as specified, replace the switch.