


## REMOVAL


### NOTICE:

If the wiring connector of the SRS is disconnected with the ignition switch at ON or ACC, diagnostic trouble codes will be recorded.



### 1. DISCONNECT AIRBAG CONNECTOR

- (a) Remove the glove compartment door.




- (b) Disconnect the airbag connector.

### NOTICE:

When handling the airbag connector, take care not to damage the airbag wire harness.


### 2. REMOVE INSTRUMENT PANEL

(See page [BO-47](#))



### 3. REMOVE FRONT PASSENGER AIRBAG ASSEMBLY

- (a) Remove the 2 bolts and front passenger airbag assembly.



- (b) Remove the 3 bolts, 2 screws and the instrument panel stay.

- (c) Remove the airbag door.

### CAUTION:

- Do not store the front passenger airbag assembly with the airbag deployment direction facing downward.
- Never disassemble the front passenger airbag assembly.