



INSPECTION

INSPECT BLOWER SPEED CONTROL SWITCH CONTINUITY

Position/Circuit	Tester connection	Specified condition
OFF	–	No continuity
LO	6 – 5	Continuity
M1	1 – 5 – 6	Continuity
M2	2 – 5 – 6	Continuity
Illumination circuit	3 – 4	Continuity

If continuity is not as specified, replace the heater control assembly or test the bulb.