


HEADLIGHT (w/o DAYTIME RUNNING LIGHT)



SERVICE HINTS**HEAD RELAY [R/B NO.2]**2-1 : Closed with light control SW at **HEAD** position or dimmer SW at **FLASH** position **: PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page	
C12	32	H2	28 (5VZ-FE)	J10	B	29 (5VZ-FE)
C14	32		30 (3RZ-FE, 2RZ-FE)			31 (3RZ-FE, 2RZ-FE)
H1	28 (5VZ-FE)	J9	A			29 (5VZ-FE)
	30 (3RZ-FE, 2RZ-FE)					31 (3RZ-FE, 2RZ-FE)

 **: RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

 **: JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1C		
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3F		

 **: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)

 **: GROUND POINTS**

Code	See Page	Ground Points Location
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

 **: SPLICE POINTS**

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire			