


# BACK-UP LIGHT



## SERVICE HINTS

**P1 (A) BACK-UP LIGHT SW [PARK/NEUTRAL POSITION SW] (A/T),**

**B1 (B) BACK-UP LIGHT SW (M/T)**

(A) 4-(A) 8, (B) 2-(B) 1 : Closed with shift lever in **R** position

**B3 BACK-UP LIGHT RELAY**

5-3 : Closed with Park/Neutral position SW at **R** position and ignition SW at **ON** position (Column A/T)

## ○ : PARTS LOCATION

Code		See Page	Code		See Page	Code	See Page
B1	B	28 (5VZ-FE)	P1	A	29 (5VZ-FE)	R7	34
		30 (3RZ-FE, 2RZ-FE)			31 (3RZ-FE, 2RZ-FE)		
B3		32	R6		34		

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3A	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3B		
3D		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

## □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)

## ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

## ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	B7	42	Frame Wire
B6	42	Frame Wire			