


# TRANSFER

## SST (Special Service Tools)

PP0AC-03

	09223-15020	Oil Seal & Bearing Replacer	Planetary gear outer bearing
	09304-12012	Input Shaft Front Bearing Replacer	Shift fork shaft oil seal
	09316-60011	Transmission & Transfer Bearing Replacer	
	(09316-00011)	Replacer Pipe	High and low clutch hub Rear output shaft bearing Front case oil seal
	(09316-00071)	Replacer "F"	Rear output shaft bearing
	09330-00021	Companion Flange Holding Tool	Companion flange
	09515-30010	Rear Wheel Bearing Replacer	Planetary gear outer bearing
	09554-22010	Differential Oil Seal Replacer	Extension housing oil seal
	09554-30011	Differential Oil Seal Replacer	Planetary gear outer bearing
	09555-55010	Differential Drive Pinion Bearing Replacer	Driven sprocket rear bearing Rear output shaft bearing Planetary gear outer bearing
	09612-65014	Steering Worm Bearing Puller	
	(09612-01030)	Claw "C"	Planetary gear inner bearing

PREPARATION - TRANSFER

	(09612-01050) Hanger Pin with Nut	Planetary gear inner bearing
	09950-40011 Puller B Set	
	(09951-04020) Hanger 200	Companion flange
	(09952-04010) Slide Arm	Companion flange
	(09953-04030) Center Bolt 200	Companion flange
	(09954-04010) Arm 25	Companion flange
	(09955-04051) Claw No.5	Companion flange
	(09957-04010) Attachment	Companion flange
	(09958-04011) Holder	Companion flange
	09950-60010 Replacer Set	
	(09951-00220) Replacer 22	Companion flange oil seal
	(09951-00350) Replacer 35	Companion flange oil seal
	(09951-00570) Replacer 57	Planetary gear inner bearing

## PREPARATION – TRANSFER

	(09951-00590) Replacer 59	Front bearing retainer oil seal
	(09952-06010) Adapter	Companion flange oil seal
	09950-70010 Handle Set	
	(09951-07100) Handle 100	Front bearing retainer oil seal Planetary gear outer bearing Planetary gear inner bearing Companion flange oil seal