


## V. REMOVE EXISTING TRAILER TOWING WIRE HARNESS CONVERTER (ALL VEHICLES)


### 1. INSPECT VEHICLE

- (a) Inspect vehicle as outlined in **Section IV** to ensure that vehicle is equipped with a Toyota trailer towing wire harness converter.




### 2. DISCONNECT THE BATTERY


- (a) Record radio station presets.
- (b) Disconnect the negative (-) battery cable.




### 3. REMOVE THE ORIGINAL CONVERTER AND TRAILER HITCH WIRING HARNESS

- (a) Unbolt the original flat four connector from the trailer hitch.
- (b) Remove the ground connection from underneath the body on the left side.
- (c) Remove any tie-wraps holding the converter wiring harness to the vehicle.






- 4. REMOVE BOTH TAILLIGHT ASSEMBLIES**
- (a) Lower tail gate.
  - (b) Remove the four mounting screws from both taillight assemblies.




- (c) Carefully remove both taillight assemblies.
- (d) Disconnect the taillight wire harness at the connector and set the assembly aside.
- (e) Disconnect the jumper connector assembly from both taillight harnesses.

**NOTE:**

- Do not allow the taillight assemblies to hang against the body by the wire harness.
- Use caution when disconnecting the taillight wire harness connectors.
- Take care not to drop the taillight assemblies.



- (f) Remove any foam or tie-wraps holding the converter harnesses to the taillight harnesses.



- (g) Remove the old converter with harness from the taillight cavity.

## 5. REINSTALL THE TAILLIGHTS

- (a) Reconnect the wire harness to each taillight.
- (b) Reinstall both taillights.
- (c) Proceed to **Section VI** for regular cab vehicles.
- (d) Proceed to **Section VII** for extra cab vehicles.