


REMOVAL

CAUTION:

Do not smoke or work near an open flame when working on the fuel pump.


1. REMOVE FUEL TANK (See page [SF-24](#))



2. REMOVE FUEL PUMP BRACKET ASSEMBLY FROM FUEL TANK

- (a) Disconnect the fuel pump connector from the clamp.
- (b) Remove the 8 bolts.

Torque: 3.4 N·m (35 kgf·cm, 30 in.-lbf)



- (c) Pull out the pump bracket assembly.
- (d) Remove the gasket from the pump bracket.

HINT:

At the time of installation, please refer to the following items.
Install a new gasket to the pump bracket.