

## DISASSEMBLY

### 1. REMOVE BULB

### 2. REMOVE HEATER CONTROL CABLES

(a) Using a screwdriver, spread the claw of the cable clamp and disconnect the outer cable.

HINT:

Tape the screwdriver tip before use.

(b) Remove the inner cable from the heater control base.