

FUEL TANK AND LINE COMPONENTS

SF040-06

CAUTION:

- Always use new gaskets when replacing the fuel tank or component parts.
- Apply the proper torque to all tightened parts.

