

## REMOVAL

1. REMOVE FRONT WHEEL  
Torque: 110 N·m (1,150 kgf·cm, 83 ft·lbf)
2. DISCONNECT SHOCK ABSORBER FROM LOWER SUSPENSION ARM

(a) Remove the shock absorber lower nut and washer.


### NOTICE:

Do not remove the bolt.


Torque: 135 N·m (1,400 kgf·cm, 101 ft·lbf)

### HINT:

At the time of installation, after stabilizing the suspension, torque the nut.



- (b) With lowering the lower suspension arm, remove the bolt and disconnect the shock absorber.



3. REMOVE SHOCK ABSORBER WITH COIL SPRING  
Remove the 3 nuts and shock absorber with the coil spring.  
Torque: 64 N·m (650 kgf·cm, 47 ft·lbf)