



INSTRUMENT PANEL COMPONENTS

BO07T-02




H01594


4WD, M/T:
Front Console Box




4WD, A/T:
Front Console Box




2WD, M/T:
Front Console Box




4WD, A/T, w/ Cup holder:
Front Console Box




4WD, M/T:
Front Console Box



2WD, A/T:
Front Console Box



Rear Console Box Cover




Upper Console Box Mounting Bracket



Rear Console Box








N·m (kgf·cm, ft·lbf) : Specified torque

H01595

HINT:

Screw shapes and sizes are indicated in the table below. The codes ("A" - "I") correspond to those indicated on the previous page.

mm (in.)								
Code	Shape	Size	Code	Shape	Size	Code	Shape	Size
(A)		∅ = 8 (0.31) L = 18 (0.71)	(B)		∅ = 6 (0.24) L = 18 (0.71)	(C)		∅ = 6 (0.24) L = 16 (0.63)
(D)		∅ = 6 (0.24) L = 25 (0.98)	(E)		∅ = 6 (0.24) L = 22 (0.87)	(F)		∅ = 5.22 (0.21) L = 16 (0.63)
(G)		∅ = 5 (0.20) L = 14 (0.55)	(H)		∅ = 8 (0.31)	(I)		∅ = 6 (0.24)

T