

## DISASSEMBLY

### 1. REMOVE CENTER BRACKET


Remove the screw and center bracket.

### 2. REMOVE NO.5 HEATER TO REGISTER DUCT

Remove the screw and No.5 heater to register duct.

### 3. REMOVE NO.2 REGISTER

Remove the 3 screws and No.2 register.



### 4. REMOVE FRONT PASSENGER AIRBAG ASSEMBLY

(a) Remove the 2 bolts and front passenger airbag assembly.

**Torque: 5.0 N·m (51 kgf·cm, 42 in.-lbf)**

(b) Remove the 3 bolts and front passenger airbag door.

(c) Remove the 3 screws and instrument panel stay.

#### CAUTION:

- Do not store the front passenger airbag assembly with the airbag side deployment direction facing down.
- Never disassemble the front passenger airbag assembly.