




\* 1 : W/ CRUISE CONTROL  
 \* 2 : W/O CRUISE CONTROL



# A/T INDICATOR (2RZ-FE)

## SERVICE HINTS

### O4 O/D MAIN SW

1-3 : Open with O/D main SW at **ON** position  
 Closed with O/D main SW at **OFF** position

### ○ : PARTS LOCATION

Code		See Page	Code	See Page	Code	See Page
C10	A	32	C17	32	O4	33
C11	B	32	D11	32	O5	31 (2RZ-FE)
C12	C	32	J11	33	P1	31 (2RZ-FE)
C13	D	32	O1	31 (2RZ-FE)		

### ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
3B	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3D		
3F		
3G	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)
3H		

### □ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IK2	40	Engine Wire and Cowl Wire (Right Kick Panel)
IK3		

### ▽ : GROUND POINTS

Code	See Page	Ground Points Location
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

### ○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	I7	40	Cowl Wire

