


VEHICLE SPEED SENSOR ON-VEHICLE REPAIR

AT01D-01

1. DISCONNECT VEHICLE SPEED SENSOR CONNECTOR



2. REMOVE VEHICLE SPEED SENSOR ASSEMBLY

- (a) Remove the bolt and the vehicle speed sensor assembly.
- (b) Remove the clip and the driven gear from the vehicle speed sensor.
- (c) Remove the O-ring from the vehicle speed sensor.

3. INSTALL VEHICLE SPEED SENSOR ASSEMBLY

- (a) Coat a new O-ring with ATF and install it to the vehicle speed sensor.
- (b) Install the driven gear and the clip to the vehicle speed sensor.
- (c) Install the vehicle speed sensor assembly with the bolt.

Torque: 16 N·m (160 kgf·cm, 12 ft·lbf)

4. CONNECT VEHICLE SPEED SENSOR CONNECTOR