

DTC	14	Actuator Mechanical Malfunction
------------	-----------	--

CIRCUIT DESCRIPTION

The circuit detects the rotation position of the actuator control plate and sends a signal to the ECU.

DTC No.	Detection Item	Trouble Area
14	<ul style="list-style-type: none"> • Cruise control actuator motor open and short 	<ul style="list-style-type: none"> • Connector of cruise control actuator and ECU • Cruise control actuator and ECU

INSPECTION PROCEDURE

1	Check connector of cruise control actuator and ECU (See page IN-28).
---	---

NG

Repair or replace connector.

OK

Check and replace cruise control actuator and ECU (See page [IN-28](#)).