

REMOVAL


1. REMOVE THESE PARTS:

- (a) Lower finish panel
- (b) Glove compartment door
- (c) No.2 Lower finish panel
(See page [BO-47](#))



2. REMOVE CENTER CLUSTER FINISH PANEL

- (a) Remove the A/C switch.
(See page [AC-83](#))
- (b) Pull out the heater control knobs.
- (c) Remove heater control name plate.
- (d) Remove the 2 screws.



- (e) Using a screwdriver, release the 4 fitting clips and pull out the panel, then disconnect the connector.



HINT:

Tap the screwdriver tip before use.

3. DISCONNECT HATER CONTROL CABLES

HINT:

After connection, adjust the control cables.



4. REMOVE HEATER CONTROL ASSEMBLY

Remove the 2 screws and pull out the heater control assembly, then disconnect the connector.