


RADIO AND PLAYER

FROM POWER SOURCE SYSTEM (SEE PAGE 46)

- * 1 : W/ AUTO ANTENNA
- * 2 : W/O AUTO ANTENNA
- * 3 : 4 SPEAKER



SERVICE HINTS**R1 (A) RADIO AND PLAYER**

- (A) 3-GROUND : Approx. **12** volts with ignition SW at **ON** or **ACC** position
 (A) 4-GROUND : Always approx. **12** volts
 (A) 7-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
A20	32	S6	34	S9	34
R1	A 33	S7	34		
R2	B 33	S8	34		

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3C	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)
3H	26	Cowl Wire and J/B No.3 (Behind the Instrument Panel Center)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IH1	40	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IL1	40	Front Door RH Wire and Cowl Wire (Right Kick Panel)
IP1	40	Floor No.3 Wire and Floor No.3 Wire (Behind the Radio and Player)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IH	40	Right Kick Panel