


REMOVAL

1. **REMOVE GLOVE COMPARTMENT DOOR**
(See page [BO-47](#))



2. **REMOVE AMPLIFIER**
 - (a) Disconnect the connector from the amplifier.
 - (b) Remove amplifier cover.
 - (c) Remove the amplifier from the cooling unit.