


Tc Terminal Circuit

CIRCUIT DESCRIPTION


Connecting terminals Tc and E₁ of the DLC1 causes the ECU to display the DTC by flashing the ABS warning light.

WIRING DIAGRAM



INSPECTION PROCEDURE

1	Check voltage between terminals Tc and E₁ of DLC1.
---	--



CHECK:

- (a) Turn the ignition switch ON.
- (b) Measure voltage between terminals Tc and E₁ of DLC1.

OK:

Voltage: 10 – 14 V

OK If ABS warning light does not blink even after Tc and E₁ are connected, the ECU may be defective.

NG

2	Check for open and short in harness and connector between ABS actuator and DLC1, DLC1 and body ground (See page IN-28).
---	--

NG

Repair or replace harness or connector.

OK

Check and replace ABS ECU.