


## TERMINALS OF ECU



F00788

Symbols (Terminal No.)	STD Voltage (V)	Condition
+ BS (A22 – 1) – GND (A22 – 2, 18)	10 – 14	Always
+ BM (A22 – 17) – GND (A22 – 2, 18)	10 – 14	Always
IG1 (A22 – 6) – GND (A22 – 2, 18)	10 – 14	IG switch ON
WA (A22 – 10) – GND (A22 – 2, 18)	Below 2.0	IG switch ON, ABS warning light ON
	10 – 14	IG switch ON, ABS warning light OFF
STP (A22 – 24) – GND (A22 – 2, 18)	Below 1.5	Stop light switch OFF
TC (A22 – 12) – GND (A22 – 2, 18)	10 – 14	IG switch ON
TS (A22 – 21) – GND (A22 – 2, 18)	10 – 14	IG switch ON
FR+ (A22 – 23) – FR– (A22 – 22)	AC generation	IG switch ON, slowly turn right front wheel
FL+ (A22 – 9) – FL– (A22 – 8)	AC generation	IG switch ON, slowly turn left front wheel
RR+ (A22 – 19) – RR– (A22 – 20)	AC generation	IG switch ON, slowly turn right rear wheel
RL+ (A22 – 5) – RL– (A22 – 4)	AC generation	IG switch ON, slowly turn left rear wheel
EXI (A22 – 7) – GND (A22 – 2, 18)	Below 2.0	IG switch ON, transfer is in L4 or H4 position
	10 – 14	IG switch ON, transfer is in H4 position
EXI2 (A22 – 14) – GND (A22 – 2, 18)	Below 2.0	IG switch ON, rear differential is locked (4WD)
	10 – 14	IG switch ON, rear differential is free (4WD)
	Below 2.0	Always (2WD)