


# Diagnosis Circuit

## CIRCUIT DESCRIPTION


This circuit sends a signal to the ECU that outputs DTC.

## WIRING DIAGRAM



**INSPECTION PROCEDURE**

- |          |  |
|----------|--|
| <b>1</b> | <b>Check voltage between terminals Tc and E<sub>1</sub> of DLC1.</b> |
|----------|--|

**CHECK:**

- (a) Turn ignition switch ON.
- (b) Measure voltage between terminals Tc and E<sub>1</sub> of DLC1.

**OK:****Voltage: 10 – 14 V****OK**

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-568](#)).

**NG**

- |          |  |
|----------|--|
| <b>2</b> | <b>Check harness and connector between cruise control ECU and DLC1, DLC1 and body ground (See page <a href="#">IN-28</a>).</b> |
|----------|--|

**NG**

Repair or replace harness or connector.

**OK**

Check and replace cruise control ECU (See page [IN-28](#)).