



REMOVAL

1. REMOVE GENERATOR DRIVE BELT

- (a) Loosen the adjusting lock nut and pivot bolt.
- (b) Loosen the adjusting bolt, and remove the drive belt.

2. REMOVE GENERATOR

- (a) Disconnect the generator connector.
- (b) Remove the nut, and disconnect the generator wire.
- (c) Remove the pivot bolt and adjusting lock nut.
- (d) Remove the generator.

Torque:

51 N·m (520kgf·cm, 38 ft·lbf) for pivot bolt

18.5 N·m (189kgf·cm, 25 ft·lbf) for adjusting lock nut