

SERVICE HINTS

TURN SIGNAL FLASHER [J/B NO.1]

3-GROUND : Approx. 12 volts with ignition SW on or hazard SW on

1-GROUND : Changes from 12 to 0 volts with ignition SW on and turn signal SW left or right, or with hazard SW on

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C12	32	F4	30 (3RZ-FE, 2RZ-FE)	J10	B
C14	32	H6	33		
F3	28 (5VZ-FE)	I15	A	R6	34
	30 (3RZ-FE, 2RZ-FE)				29 (5VZ-FE)
F4	28 (5VZ-FE)	J9	A		31 (3RZ-FE, 2RZ-FE)

○ : RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
2	21	R/B No.2 (Engine Compartment Left)

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	22	Cowl Wire and J/B No.1 (Lower Finish Panel)
1C		
1F	22	Engine Room Main Wire and J/B No.1 (Lower Finish Panel)
3F	24	Cowl Wire and J/B No.3 (Behind the Instrument Panel Left)

□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IF1	40	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
BN1	42	Frame Wire and Cowl Wire (Under the Driver's Seat)

▽ : GROUND POINTS

Code	See Page	Ground Points Location
EA	36 (5VZ-FE)	Front Left Fender
	38 (3RZ-FE, 2RZ-FE)	
IE	40	Around the Right Edge of the Reinforcement
IG	40	Around the Left Edge of the Reinforcement

○ : SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
I6	40	Cowl Wire	B7	42	Frame Wire