

## REMOVAL

### 1. DISCHARGE REFRIGERANT FROM REFRIGERATION SYSTEM


HINT:

At the time of installation, please refer to the following item.

Evacuate air from refrigeration system.

Charge system with refrigerant and inspect for leakage of refrigerant.

**Specified amount: 600 ± 50 g (21.16 ± 1.76 oz.)**



I02322

### 2. DISCONNECT SUCTION TUBE AND LIQUID TUBE FROM COOLING UNIT FITTINGS

Torque:

**Liquid tube: 14 N·m (140 kgf·cm, 10 ft·lbf)**

**Suction tube: 32 N·m (330 kgf·cm, 24 ft·lbf)**

NOTICE:

**Cap the open fittings immediately to keep moisture or dirt out of the system.**

HINT:

At the time of installation, please refer to the following item.


Lubricate 2 new O-rings with compressor oil and install the tubes.

### 3. REMOVE 2 GROMMETS

### 4. REMOVE DRAIN PIPE GROMMET

### 5. REMOVE THESE PARTS:

- (a) Glove compartment door
- (b) Glove compartment door reinforcement
- (c) Lower No. 2 finish panel
- (d) No. 4 heater to register duct



N14283

### 6. REMOVE COOLING UNIT

- (a) Disconnect the connectors.
- (b) Remove the 3 screws, bolt and the cooling unit.