



HEATER MAIN RELAY INSPECTION

AC08X-01

INSPECT HEATER MAIN RELAY (Making: HTR) CONTINUITY

| Condition | Tester connection | Specified condition |
|------------------------------------|-------------------|---------------------|
| Constant | 2 - 4 3 - 5 | Continuity |
| Apply B+ between terminals 3 and 5 | 1 - 2 | Continuity |

If continuity is not as specified, replace the relay.