



INSTALLATION

Installation is in the reverse order of removal (See page [PR-11](#)).

HINT:

- Propeller shaft (pre runner) and rear propeller shaft (4WD) of 3-joint type:
Center bearing center line and the center bearing housing center line must be adjusted within 0 ± 1 mm (0 ± 0.04 in.) of each other in the vehicles front and rear direction when the vehicle is unloaded.
- Propeller shaft (pre runner) and rear propeller shaft (4WD) of 3-joint type:
When adjusting the center bearing housing center line, it should be perpendicular to the axis of front propeller shaft.
- With a grease gun, pump grease into each fitting until it begins to flow around the oil seal.

Grease:

Spiders:

Lithium base chassis grease, NLGI No. 2.

Sleeve yoke and double cardan joint:

Molybdenum disulfide lithium base chassis grease, NLGI No. 2.