

WATER VALVE

AC08H-01

ON-VEHICLE INSPECTION

1. **WARM UP ENGINE**
2. **DISCONNECT WATER VALVE CONTROL CABLE**
3. **INSPECT WATER VALVE OPERATION**
 - (a) Check that warm air blown out the vent when the water valve lever is moved to "WARM" position.
 - (b) Check that cool air blown out when the water valve is moved to the "COOL" position.

If operation is not as specified, replace the water valve.

4. **CONNECT WATER VALVE CONTROL CABLE**

After connection, adjust the control cable.