


REMOVAL

1. REMOVE BRAKE LINE COVER

2. DISCONNECT CONNECTOR

Pull out the release bar, and disconnect the connector.



3. DISCONNECT BRAKE LINES

Using SST, disconnect the 5 brake lines from the ABS actuator.

SST 09023-00100

Torque: 15 N·m (155 kgf·cm, 11 ft·lbf)

4. REMOVE ABS ACTUATOR ASSEMBLY

Remove the bolt, 2 nuts and ABS actuator assembly.

Torque: 19 N·m (195 kgf·cm, 14 ft·lbf)

5. REMOVE ABS ACTUATOR

Using a T25 torx wrench, remove the 3 bolts and ABS actuator from actuator bracket.

Torque: 9.0 N·m (91.8 kgf·cm, 80 in·lbf)