


CRUISE MAIN Indicator Light Circuit

CIRCUIT DESCRIPTION


When the cruise control main switch is turned ON, CRUISE MAIN indicator light lights up.

WIRING DIAGRAM



INSPECTION PROCEDURE

- 1 Check voltage between terminals PI and GND of cruise control actuator and ECU connector.

**PREPARATION:**

Ignition switch ON.

CHECK:

Measure voltage between terminals PI and GND of cruise control ECU connector when the main switch on and off.

OK:

Switch position	Voltage
OFF	10 – 16 V
ON	Below 1.2 V

OK

Proceed to next circuit inspection shown on problem symptoms table. (See page [DI-621](#))

NG

- 2 Check combination meter (See page [BE-2](#)).

NG

Replace combination meter.

OK

Check and replace cruise control actuator and ECU (See page [IN-28](#)).