


## REMOVAL

### 1. REMOVE DOOR SCUFF PLATE

Remove the 4 screws and plate.



### 2. REMOVE BACK PANEL UPPER GARNISH AND BACK PANEL TRIM


- (a) Using a screwdriver, remove the back panel upper garnish.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 3 bolts and back panel trim.

**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**



### 3. REMOVE BACK PANEL LOWER GARNISH

Using a screwdriver, remove the back panel lower garnish.

HINT:

Tape the screwdriver tip before use.

### 4. REMOVE REAR SEAT CUSHIONS


Remove the 4 bolts and rear seat cushions.

**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**

### 5. REMOVE FRONT AND REAR SEAT OUTER BELT ANCHORS

Remove the 4 bolts, seat belt anchors and belt guide.

**Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)**




### 6. REMOVE LOCK HANDLE

- (a) Using a screwdriver, remove the cover.

HINT:

Tape the screwdriver tip before use.

- (b) Remove the 2 screws and lock handle.



### 7. REMOVE QUARTER TRIM


- (a) Remove the screw and coat hook.
- (b) Using a screwdriver, remove the quarter trim.

#### NOTICE:

Paying enough attention remove the clip on the quarter trim shown in the illustration. Otherwise, the quarter trim or the front pillar garnish might be broken.


#### HINT:

Tape the screwdriver tip before use.



### 8. REMOVE QUARTER WINDOW GLASS

- (a) Remove the 4 nuts and quarter window glass.



- (b) Remove the lock handle from the quarter window glass.
- (c) Remove the 2 hinges from the quarter window glass.