


DTC	48	Rear Differential Lock Circuit (w/ Rear Differential Lock)
------------	-----------	---

CIRCUIT DESCRIPTION

DTC No.	DTC Detecting Condition	Trouble Area
48	Open or short circuit in rear differential lock circuit. Rear differential is locking.	<ul style="list-style-type: none"> • Rear differential lock • ECU

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

Rear differential lock switch is OFF.

1	Check the rear differential lock is free (See page SA-202).
----------	--

NG

Repair the rear differential lock system.

OK

2	Is DTC output?
---	----------------

Check DTC on page [DI-415](#).

NO

Normal.

YES

3	Check that REAR DIFF. LOCK indicator light does not go off.
---	---

NO

Go to step NO TAG.

YES

4	Check that bulb for REAR DIFF. LOCK indicator light is not burnt out.
---	---

YES

Replace indicator light.

NO

5	Check for open in harness and connector between battery and REAR DIFF. LOCK indicator light, REAR DIFF. LOCK indicator light and ABS ECU (See page IN-28).
---	---

NG

Repair or replace harness or connector.

OK

6	Check for short in harness and connector between REAR DIFF. LOCK indicator light and ABS ECU (See page IN-28).
---	---

NG

Repair or replace harness or connector.

OK

Check and replace ABS ECU.