

DISASSEMBLY


1. w/o Power window:

REMOVE REGULATOR HANDLE

Pull off the snap ring with a cloth and remove the regulator handle and plate.

HINT:

At the time of reassembly, please refer to the following item. With door window fully closed, install the plate and regulator handle with the snap ring.



2. REMOVE DOOR INSIDE HANDLE


- (a) Remove the screw and slide the handle forward.
- (b) Disconnect the handle from the control link and remove the handle.

3. REMOVE INNER COVER

Using a screwdriver, remove the inner cover.

HINT:

Tape the screwdriver tip before use.



4. w/o Power window:

REMOVE DOOR TRIM

- (a) Remove the clip.
- (b) w/ Wide armrest: Remove the 2 caps and 2 screws from the armrest.
- (c) Insert a screwdriver between the retainer and door trim to pry it loose.

NOTICE:

Be careful not to damage the door and door trim.


HINT:

Tape the screwdriver tip before use.

- (d) Pull the trim upward to remove it.

- (e) w/ Wide armrest:

Remove the 5 screws and armrest.



5. w/ Power window:

REMOVE DOOR TRIM

- (a) Remove the clip.
- (b) Remove the armrest panel by pulling upward, then disconnect the connectors.
- (c) Remove the 2 caps and 2 screws.
- (d) Insert a screwdriver between the retainer and door trim to pry it loose.

NOTICE:

Be careful not to damage the door and door trim.


HINT:

Tape the screwdriver tip before use.

- (e) Pull the trim upward to remove it.
- (f) Remove the 5 screws and armrest.

6. REMOVE DOOR SPEAKER

- (a) Disconnect the connector.
- (b) Remove the 5 screws and speaker.

**7. REMOVE SERVICE HOLE COVER**

- (a) Remove the 2 grommets.
- (b) Remove the service hole cover.

HINT:

At the time of reassembly, please refer to the following item. Bring out the link and connector through the service hole cover.

8. REMOVE OUTER REAR VIEW MIRROR

- (a) w/ Remote control:
Disconnect the connector.
- (b) Remove the 3 bolts and outer rear view mirror.

9. REMOVE OUTER WEATHERSTRIP**10. REMOVE GLASS RUN****11. REMOVE FRONT LOWER FRAME**

Remove the bolt, nut and front lower frame.

12. REMOVE DOOR GLASS**HINT:**

Insert a shop rag inside the door panel to prevent scratching the glass.

- (a) Open the door glass until the nuts appear in the service hole.
- (b) Remove the 2 bolts and door glass.

NOTICE:


Do not damage the door glass.

HINT:


Pull the glass upward to remove it.

13. REMOVE REAR LOWER FRAME

Remove the bolt, nut, and rear lower frame.

**14. REMOVE WINDOW REGULATOR**

- (a) w/o Power window:
Remove the 5 bolts and regulator.
Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)
- (b) w/ Power window:
Disconnect the connector, then remove the 6 bolts and window regulator.
Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)



HINT:

At the time of reassembly, please refer to following item.
Apply MP grease to the window regulator rollers.

NOTICE:

At the time of reassembly, please refer to the following item.

Do not apply grease to the spring of the window regulator.


15. REMOVE DOOR LOCK

- (a) Disconnect the 2 links from the outside handle.
- (b) w/ Power door lock:
Disconnect the connector.
- (c) Remove the 3 screws and door lock.

HINT:

At the time of reassembly, please refer to following items.

- Apply adhesive to the 3 screws.
Part No.08833-00070, THREE BOND 1324 or equivalent



- Apply MP grease to the sliding and rotating parts of the door lock.

16. REMOVE OUTSIDE HANDLE

- (a) Remove the 2 bolts.
Torque: 4.9 N·m (50 kgf·cm, 43 in.-lbf)
- (b) Remove the lock cylinder.